




Manual

V BOT

4K HDMI Loop Camera Motorized Head




White Balance




WB Auto

Used to set the selected white balance auto.



WB Manual


Used to set the selected white balance MANUAL using the knob.



WB R Gain

(-50 ~ 50)


- When the white balance is set to MANUAL, the indicator lights up in green and the R-GAIN value changes.




WB B Gain

(-50 ~ 50)

- When the white balance is set to MANUAL, the indicator lights up in green and the B-GAIN value changes.




AWB Hold Off




AWB Hold On

Auto Exposure Setting




AE auto

Used to set the selected exposure to AUTO.




AE manual

Used to set the selected exposure to MANUAL using the knob.




AE Shutter Speed Up/Down

When auto exposure is set to MANUAL or SHUTTER, the indicator lights up in red and the Shutter speed changes.



AE IRIS Up/Down


When auto exposure is set to MANUAL or IRIS priority, the indicator lights up in red and the Iris value changes




AE Gain Up/Down

When auto exposure is set to MANUAL, the indicator lights up in red and the Gain value changes

Auto Exposure Setting IRIS priority




- In auto exposure mode, it is set to IRIS priority
- Shutter auto
- Gain auto
- IRIS manual




AE BRIGHT Up/Down

- When auto exposure is set to Bright, the indicator lights up in red and the Bright value changes.



AE IRIS Up/Down


- When auto exposure is set to MANUAL or IRIS priority, the indicator lights up in red and the Iris value




AE Gain Limit Up/Down

- When auto exposure is set to IRIS priority, the indicator lights up in red and the Gain Limit value

Auto Exposure Setting SHUTTER priority.




- In auto exposure mode, it is set to SHUTTER priority.
- Shutter speed
- Gain auto
- IRIS auto



AE B Right Up/Down

- When auto exposure is set to Bright, the indicator lights up in red and the Bright value changes.



AE Shutter Speed Up/Down

- When auto exposure is set to MANUAL or SHUTTER, the indicator lights up in red and the Shutter value changes.